

Optical fiber splice and distribution box. 2 input/output ports. 12 splices and 16 outputs





| • | Splice or | r small | distribu | ution | box | for | ind | oor | use | e w | ith |
|---|-------------------------------|---------|----------|-------|-----|-----|-----|-----|-----|-----|-----|
| | 2 input/ | output | ports. | | | | | | | | |
| | | | | | | | | | | | |

Universal splice tray with universal splice holder, Capacity: 12 fusion (double height) and 16 outgoing ports for subscriber connections.

Made of quality PC+ABS.

| MODEL | | RSE-121 | | | | | |
|----------------------|------------------|-----------------------------|--|--|--|--|--|
| REF. | | 8295 | | | | | |
| Manufacturing mat | terial | ABS + PC | | | | | |
| Index of protection | IP | IP44 | | | | | |
| | Width | 200 mm | | | | | |
| Dimensions | Height | 126 mm | | | | | |
| | Depth | 50 mm | | | | | |
| Cover | | Removable Cover | | | | | |
| Closing system | | 4 clips | | | | | |
| Colour | | White colour | | | | | |
| Input/Output | Diameter | 4 dies 10 / 20 mm | | | | | |
| entrance | Fixing | Flange anchor | | | | | |
| Fiber splice tray | | 1 | | | | | |
| Total capacity for f | usions | 12 | | | | | |
| Fibre routing guide | • | Integrated in the tray | | | | | |
| Curvature radius | | 45 mm | | | | | |
| Fastening wiring | 4 flanges | Integrated in trays | | | | | |
| Caps | 2 anti-dust caps | 50 mm | | | | | |
| Adapters | Not included | 8 nylon flanges (70x2.5 mm) | | | | | |
| Heat-shrinkable sp | olice protector | 12 units | | | | | |

Installations