

RELEASE NOTES

Product: ONE+ (ref. 2865)

ONE+ SAT (ref. 2864)

Version: 1.0.1

Date: 27/03/19

1. GENERAL INFORMATION

1.1 Purpose and coverage

The ONE+ and ONE+ SAT are programmable digital amplifiers, designed to selectively filter TV channels. Suitable for both household requirements and for collective housing, they are the perfect solution for managing signals of different frequencies and amplitudes.

This document describes the new features, compatibility issues, solved problems, and known issues to solve associated with this product relea

1.2 List of releases

- 1.0.1
- 1.0.0

1.3 Product identification

1.3.1 Software review

Software release of the system is checked through the user interface in the OLED display.

Go to ADVANCED → DEVICE INFO. → FW VERSION. Check firmware version information.

RELEASE NOTES
Product: ONE+, ONE+ SAT



ONE+ SAT v1.0.0 IKUSI Feb 18 2019 <

1.3.2 Hardware review

Not applicable. All HW versions are supported.

1.4 Compatibility information

1.4.1 Supported HW

Not applicable. All HW versions are supported.

1.4.2 Backwards compatibility notes

It is not possible to downgrade.

2. RELEASE HISTORY

- Software release 3.0.3 (01/03/2019)
 - New features
 - None.
 - Resolved issues
 - The output level configured by the user did not keep after rebooting the device.
 - After loading a configuration, the output level stored in that configuration was not used.
 - The alarm of excessive output level did not disappear after a reset factory default.
 - Some errata in the text of the user interface have been corrected.
 - Known issues
 - None.


RELEASE NOTES

Product: ONE+, ONE+ SAT



3. UPGRADE INSTRUCTIONS

3.1 Installation environment



3.2 Equipment/modules checking

In order to ensure that there is no hardware issues check that there are not active hw alarms.

3.3 Software upgrade procedure

Follow these steps:

 Download the latest version from our website https://www.ikusi.tv/en/products/one-sat

RELEASE NOTES

Product: ONE+, ONE+ SAT



P° Miramón, 170 · 20014 San Sebastián · SPAIN Tel.: +34 943 44 89 44 · Fax: +34 943 44 88 20 television@ikusi.com.www.ikusi.tv

- Store the firmware file with the new version on a microSD memory card in the ONE\Firmware folder.
- Insert the microSD memory card into the equipment
- Select the option ADVANCED → SD CARD → FW UPGRADE. A list with the firmware files included on the microSD memory card will be shown.
- Select the desired file and launch the update.
- After a while, (approximately 20 seconds) the update will conclude and the equipment will reboot.